

Electric Pallet Truck Onboard


Pallet Weight & Dimensioning Verification



Challenges / Solutions Facing Shipping Departments

More efficient and productive means for companies using floor scales to try and keep up with shipping data demands from freight transportation companies

Automatic Measurement Cycle with Data Download to USB Port or Mobile Printer (No operator Input)



Lift Truck ID# Operator Login ID# SDRAM Clear







SELECT PALLET HEIGHT = 93_ SkidWeigh



Session Start (Load on the ground)

* 1. Scan product ID#

(If barcode scanner faulty or code can't be read, press external button to input product ID# via keypad)

* With product ID# in the system the LCD display will move automatically to the pallet size menu.

* 2. Pallet Size Menu

(All standard industry pallet sizes)

- Default pallet size is **48 x 40** after barcode on manual ID# inputed into the system
- * Use scroll key to change size
- * Use manual input for non standard pallet size or larger freight

* 3. Select Pallet Height

- * Input pallet height and press enter key
- * Should pallet load be not on ground the LCD display will show "LOWER FORKS"

* 4. Lift Loaded Forks

(Activate and hold lift control until loaded forks automatically will stop)

- * LCD display will show, "PLEASE WAIT"
- * Within few seconds LCD display will show lifted load weight

Session Finished

The automatic measurement cycle is completed and data will be send to USB port or onboard printer. (No operator input required)



